

Kit Inhalte

| | | | |
|-------------|-------------------------|--|---|
| LJ2100 | Paper-Feed-Kit PFK-2100 | | |
| | RB2-2900 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RB2-2891 | Pickup Roller 250 Sheet Tray (Tray 2 / Tray 3) | 2 |
| | RB2-2835/RB2-6348 | Separation Pad MP Tray (Tray 1) | 1 |
| | RB2-3008/RB9-0695 | Separation Pad 250 Sheet Tray (Tray 2) | 2 |
| | RB2-3007 | Small Separation Pad (Sticks on Metal Lifting Plate in Tray) | 2 |
| | RB2-2886 | Small Separation Pad (Sticks on MP Tray/Tray 1) | 1 |
| | Maintenance-Kit MK-2100 | | |
| | RG5-4133 | Fuserunit | 1 |
| | RB2-2900 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RB2-2891 | Pickup Roller 250 Sheet Tray (Tray 2 / Tray 3) | 2 |
| | RB2-2835/RB2-6348 | Separation Pad MP Tray (Tray 1) | 1 |
| | RB2-3008/RB9-0695 | Separation Pad 250 Sheet Tray (Tray 2) | 2 |
| | RG5-4164 | Transfer Roller | 1 |
| LJ2200 | Paper-Feed-Kit PFK-2100 | | |
| | RB2-2900 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RB2-2891 | Pickup Roller 250 Sheet Tray (Tray 2 / Tray 3) | 2 |
| | RB2-2835/RB2-6348 | Separation Pad MP Tray (Tray 1) | 1 |
| | RB2-3008/RB9-0695 | Separation Pad 250 Sheet Tray (Tray 2) | 2 |
| | RB2-3007 | Small Separation Pad (Sticks on Metal Lifting Plate in Tray) | 2 |
| | RB2-2886 | Small Separation Pad (Sticks on MP Tray/Tray 1) | 1 |
| | Maintenance-Kit MK-2200 | | |
| | RG5-5569 | Fuserunit | 1 |
| | RG5-5581 | Transfer Roller Assembly | 1 |
| | RB2-2900 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RB2-2891 | Pickup Roller Tray 2/3 | 2 |
| | RB2-6474/RB2-3008 | Separation Pad 500 Sheet Tray (Tray 3) | 2 |
| | RF5-3272/RB2-2835 | Separation Pad MP Tray (Tray 1) | 1 |
| LJ2300 | Paper-Feed-Kit PFK-2300 | | |
| | RC1-0945 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RB2-2891 | Pickup Roller Tray 2/3 | 2 |
| | RC1-0939 | Separation Pad MP Tray (Tray 1) | 1 |
| | RC1-0954 | Separation Pad 250 Sheet Tray (Tray 1) | 1 |
| | RF5-4258 | Separation Pad 500 Sheet Papertray (Tray 2) | 1 |
| | Maintenance-Kit U6180 | | |
| | RM1-0355 | Fuserunit | 1 |
| | RM1-0343 | Transfer Roller Assembly | 1 |
| | RC1-0945 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RB2-2891 | Pickup Roller Tray 2/3 | 2 |
| | RC1-0939 | Separation Pad MP Tray (Tray 1) | 1 |
| | RC1-0954 | Separation Pad 250 Sheet Tray (Tray 1) | 1 |
| | RF5-4258 | Separation Pad 500 Sheet Papertray (Tray 2) | 1 |
| LJ2400 | Paper-Feed-Kit PFK-2400 | | |
| | RL1-0568 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RL1-0542 | Pickup Roller Tray 2 | 1 |
| | RC1-0939 | Separation Pad MP Tray (Tray 1) | 1 |
| | RM1-1298 | Separation Pad Tray 2 | 1 |
| | Maintenance-Kit MK-2400 | | |
| | RM1-1531 | Fuserunit | 1 |
| | RM1-1508 | Transfer Roller Assembly | 1 |
| | RL1-0568 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RL1-0542 | Pickup Roller Tray 2 | 1 |
| | RC1-0939 | Separation Pad MP Tray (Tray 1) | 1 |
| | RB2-6349/RB2-3008 | Separation Pad Tray 2 | 1 |
| LJ4000/4050 | Paper-Feed-Kit PFK-4000 | | |
| | RG5-3718 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-2490/RF5-1885 | Feed/Sep Roller 500 Sheet Tray (Tray 2) (2 used) | 4 |
| | RB1-8865 | Pickup D-Roller 500 Sheet Tray (4 used) | 4 |
| | RB1-8773/RG5-5281 | Separation Pad MP Tray (Tray 1) | 1 |
| | Maintenance-Kit C4118 | | |
| | RG5-2662 | Fuserunit | 1 |
| | RG5-4283 | Transfer Roller Assembly | 1 |
| | RF5-2490/RF5-1885 | Feed/Sep Roller 500 Sheet Tray (Tray 2) (2 used) | 4 |
| | RG5-3718 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RB1-8773/RG5-5281 | Separation Pad MP Tray (Tray 1) | 1 |

| | | | |
|-----------------------|-----------------------------------|--|---|
| LJ4100 | Paper-Feed-Kit PFK-4100 | | |
| | RG5-3718 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-3114 | Feed/Sep Roller 500 Sheet Tray (Tray 2) (2 used) | 4 |
| | RB1-8957 | Pickup D-Roller (500 Sheet Tray) (4 used) | 4 |
| | RF5-3086 | Separation Pad (MP Tray) | 1 |
| | Maintenance-Kit C8058 | | |
| | RG5-5064 | Fuserunit | 1 |
| | RG5-5295 | Transfer Roller Assembly | 1 |
| | RF5-3114 | Feed/Sep Roller 500 Sheet Tray (Tray 2) (2 used) | 4 |
| | RF5-3086 | Separation Pad (MP Tray) | 1 |
| | RG5-3718 | Pickup Roller MP Tray (Tray 1) | 1 |
| LJ4200/4250/4350/4300 | Paper-Feed-Kit PFK-4200 | | |
| | RL1-0019 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RM1-0036 | Pickup Roller Tray 2 + 1500 Sheetfeeder | 3 |
| | RM1-0037 | Paper Feed Roller Tray 2 + 1500 Sheetfeeder | 6 |
| | RL1-0007 | Separation Pad MP Tray (Tray 1) | 1 |
| | 4200 Maintenance-Kit Q2430 | | |
| | RM1-0014 | Fuserunit | 1 |
| | RM1-0699 | Transfer Roller Assembly | 1 |
| | RL1-0019 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RM1-0036 | Pickup Roller Tray 2 + 1500 Sheetfeeder | 2 |
| | RM1-0037 | Paper Feed Roller Tray 2 + 1500 Sheetfeeder | 4 |
| | RL1-0007 | Separation Pad MP Tray (Tray 1) | 1 |
| | 4250 / 4350 Maintenance-Kit Q5422 | | |
| | RM1-1083 | Fuserunit | 1 |
| | RM1-1110 | Transfer Roller | 1 |
| | RL1-0019 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RM1-0036 | Pickup Roller Tray 2 + 1500 Sheetfeeder | 3 |
| | RM1-0037 | Paper Feed Roller Tray 2 + 1500 Sheetfeeder | 6 |
| | RL1-0007 | Separation Pad MP Tray (Tray 1) | 1 |
| | 4300 Maintenance-Kit Q2437 | | |
| | RM1-0102 | Fuserunit | 1 |
| | RM1-0699 | Transfer Roller Assembly | 1 |
| | RL1-0019 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RM1-0036 | Pickup Roller Tray 2 + 1500 Sheetfeeder | 3 |
| | RM1-0037 | Paper Feed Roller Tray 2 + 1500 Sheetfeeder | 6 |
| | RL1-0007 | Separation Pad MP Tray (Tray 1) | 1 |
| LJ5Si/8000 | Paper-Feed-Kit PFK-5si | | |
| | RF5-1834 | Feed/Separation Roller (In paper Input Unit, 4 used) | 6 |
| | RF5-1835 | Pickup Roller (In Paper Input Unit, 2 used) | 3 |
| | RB1-6730 | Pickup Roller (MP Tray) | 1 |
| | RF5-1455 | Separation Pad (MP Tray) | 1 |
| | Maintenance-Kit C3972 | | |
| | RG5-4448 | Fuser Unit | 1 |
| | RF5-1412 | Transfer Charge Roller | 1 |
| | RF5-1834 | Feed/Separation Roller (In paper Input Unit, 4 used) | 4 |
| | RF5-1835 | Pickup Roller (In Paper Input Unit, 2 used) | 2 |
| LJ5000 | Paper-Feed-Kit PFK-5000 | | |
| | RB2-1820 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RB2-1821 | Pickup Roller 250 Sheet Tray (Tray 2) | 2 |
| | RB1-8865 | Pickup D-Roller 500 Sheet Tray (4 used) | 4 |
| | RF5-2634 | Feed Roller 500 Sheet Tray | 2 |
| | RG9-1310/RG9-1485 | Separation Pad 250 Sheet Tray (Tray 2) | 2 |
| | RF5-2400/RF5-3439 | Separation Pad MP Tray (Tray 1) | 1 |
| | RF5-4117/RF5-2399 | Sub Pad MP Tray (Tray 1) (2 used) | 2 |
| | Maintenance-Kit C4110 | | |
| | RG5-5460 | Fuserunit | 1 |
| | RG5-3579 | Transfer Roller | 1 |
| | RB2-1820 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RB2-1821 | Pickup Roller 250 Sheet Tray (Tray 2) | 2 |
| | RB1-8865 | Pickup D-Roller 500 Sheet Tray (4 used) | 4 |
| | RF5-2634 | Feed Roller 500 Sheet Tray | 2 |
| | RG9-1310/RG9-1485 | Separation Pad 250 Sheet Tray (Tray 2) | 2 |
| | RF5-2400/RF5-3439 | Separation Pad MP Tray (Tray 1) | 1 |
| | RF5-4117/RF5-2399 | Sub Pad MP Tray (Tray 1) (2 used) | 2 |
| LJ5100 | Paper-Feed-Kit PFK-5100 | | |
| | RB2-1820 | Pickup Roller MP Tray (Tray 1) | 1 |

| | | | |
|--------------|------------------------------|--|---|
| | RB2-1821 | Pickup Roller 250 Sheet Tray (Tray 2) | 2 |
| | RB1-8865 | Pickup D-Roller 500 Sheet Tray (4 used) | 4 |
| | RF5-2634 | Feed Roller 500 Sheet Tray | 2 |
| | RF5-4119 | Separation Pad MP Tray (Tray 1) | 1 |
| | RF5-4120 | Separation Pad 250 Sheet Tray (Tray 2) | 2 |
| | RF5-4117/RF5-2399 | Sub Pad MP Tray (Tray 1) (2 used) | 2 |
| | Maintenance-Kit Q1860 | | |
| | RG5-7061 | Fuserunit | 1 |
| | RG9-1542 | Transfer Roller | 1 |
| | RB2-1820 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RB2-1821 | Pickup Roller 250 Sheet Tray (Tray 2) | 2 |
| | RB1-8865 | Pickup D-Roller 500 Sheet Tray (4 used) | 4 |
| | RF5-2634 | Feed Roller 500 Sheet Tray | 2 |
| | RF5-4119 | Separation Pad MP Tray (Tray 1) | 1 |
| | RF5-4120 | Separation Pad 250 Sheet Tray (Tray 2) | 2 |
| | RF5-4117/RF5-2399 | Sub Pad MP Tray (Tray 1) (2 used) | 2 |
| LJ8100/8150 | Paper-Feed-Kit PFK-8100 | | |
| | RF5-1834 | Feed/Separation Roller (In Paper Input Unit, 4 used) | 6 |
| | RF5-1835 | Pickup Roller (In Paper Input Unit, 2 used) | 1 |
| | RF5-2708 | Pickup Roller (In Paper Input Unit, 2 used) | 2 |
| | RB1-9526 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-2703 | Separation Pad MP Tray (Tray 1) | 1 |
| | Maintenance-Kit C3915 | | |
| | RG5-6533/ RG5-4319 | Fuser Unit | 1 |
| | RF9-1394 | Transfer Roller | 1 |
| | RF5-1834 | Feed/Separation Roller (In Paper Input Unit, 4 used) | 4 |
| | RF5-2708 | Pickup Roller (In Paper Input Unit, 2 used) | 2 |
| LJ9000 | Paper-Feed-Kit PFK-9000 | | |
| | RF5-3403 | Pickup Roller Optional MP Tray (Tray 1) | 1 |
| | RF5-3404 | Separation Roller Optional MP Tray (Tray 1) | 1 |
| | RF5-3340 | Pickup Feed/Separation Roller (Tray 2) | 2 |
| | RF5-3338 | Pickup Feed/Separation Roller (Tray 2) | 8 |
| | Maintenance-Kit C9153 | | |
| | RG5-5751 | Fuserunit | 1 |
| | RG5-5662 | Transfer Roller Assembly | 1 |
| | RF5-3340 | Pickup Feed/Separation Roller (Tray 2) | 2 |
| | RF5-3338 | Pickup Feed/Separation Roller (Tray 2) | 7 |
| CLJ4500/4550 | Paper-Feed-Kit PFK-4500 | | |
| | RB2-0717 | Smaller Pickup Roller MP Tray (Tray 1) | 1 |
| | RB2-0744 | Larger Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-2092 | Pickup Roller Tray 2 and Tray 3 | 2 |
| | RB1-8865 | Pickup D-Roller (500 Sheet Tray) (4 used) | 8 |
| | RF5-2490/RF5-1885 | Feed/Sep Roller 500 Sheet Tray (Tray 2) (2 used) | 4 |
| | RB2-0734 | Separation Pad MP Tray (Tray 1) | 1 |
| | Maintenance-Kit MK-4500 | | |
| | RG5-3251/RG5-5155 | Fuser Unit | 1 |
| | RF5-2112 | Transfer Roller | 1 |
| | RB2-0717 | Smaller Pickup Roller MP Tray (Tray 1) | 1 |
| | RB2-0744 | Larger Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-2092 | Pickup Roller Tray 2 and Tray 3 | 1 |
| | RB1-8865 | Pickup Roller (500 Sheet Tray) (4 used) | 8 |
| | RF5-2490/RF5-1885 | Feed/Sep Roller 500 Sheet Tray (Tray 2) (2 used) | 4 |
| | RB2-0734 | Separation Pad MP Tray (Tray 1) | 1 |
| CLJ4600/4650 | Paper-Feed-Kit PFK-4600 | | |
| | RG9-1529 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-3739 | Pickup Roller Tray 2 (2 used) | 4 |
| | RF5-3750 | Separation Pad Tray 2 | 2 |
| | 4600 Maintenance-Kit MK-4600 | | |
| | RG5-6517 | Fuser Unit | 1 |
| | RG9-1529 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-3739 | Pickup Roller Tray 2 (2 used) | 4 |
| | RF5-3750 | Separation Pad Tray 2 | 2 |
| | 4650 Maintenance-Kit MK-4650 | | |
| | RG5-7451 | Fuser Unit | 1 |
| | RG9-1529 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-3739 | Pickup Roller Tray 2 (2 used) | 4 |
| | RF5-3750 | Separation Pad Tray 2 | 2 |

| | | | |
|--------------------|------------------------------|--|---|
| CLJ4700 | Paper-Feed-Kit PFK-4700 | | |
| | RL1-0019 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-3750 | Separation Pad Tray 2 | 1 |
| | RM1-0036 | Pickup Roller Tray 2 | 3 |
| | RM1-0037 | Paper Feed Roller Tray 2 | 6 |
| | Maintenance-Kit MK-4700 | | |
| | RM1-3146 | Fuser Unit | 1 |
| | RL1-0019 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-3750 | Separation Pad Tray 2 | 1 |
| | RM1-0036 | Pickup Roller Tray 2 | 3 |
| | RM1-0037 | Paper Feed Roller Tray 2 | 6 |
| CLJ5500/5550 | Paper-Feed-Kit PFK-5500 | | |
| | RG9-1529 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-3340 | Pickup Feed/Separation Roller (Tray 2) | 2 |
| | RF5-3338 | Pickup Feed/Separation Roller (Tray 2) | 4 |
| | RF5-3865 | Separation Pad MP Tray (Tray 1) | 1 |
| | 5500 Maintenance-Kit MK-5500 | | |
| | RG5-6701 | Fuserunit | 1 |
| | RG9-1529 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-3340 | Pickup Feed/Separation Roller (Tray 2) | 2 |
| | RF5-3338 | Pickup Feed/Separation Roller (Tray 2) | 4 |
| | RF5-3865 | Separation Pad MP Tray (Tray 1) | 1 |
| | 5550 Maintenance-Kit MK-5550 | | |
| | Q3985-67901 | Fuserunit | 1 |
| | RG9-1529 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-3340 | Pickup Feed/Separation Roller (Tray 2) | 2 |
| | RF5-3338 | Pickup Feed/Separation Roller (Tray 2) | 4 |
| | RF5-3865 | Separation Pad MP Tray (Tray 1) | 1 |
| CLJ 8500/8550 | Paper-Feed-Kit PFK-8500 | | |
| | RB1-9526 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RF5-1834 | Feed/Separation Roller (4 used) | 6 |
| | RF5-1835 | Pickup Roller (In Paper Input Unit, 2 used) | 3 |
| | RF5-1989 | Separation Pad MP Tray (Tray 1) | 1 |
| CLJ 3500/3550/3700 | Paper-Feed-Kit PFK-3500 | | |
| | RC1-1535 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RM1-0731 | Pickup Roller 250+500 Sheet Tray (Tray 2/3) | 2 |
| | RC1-0939 | Separation Pad MP Tray (Tray 1) | 1 |
| | RC1-0954 | Separation Pad 250 Sheet Tray (Tray 2) | 1 |
| | RM1-0827 | Separation Pad 500 Sheet Tray (Tray 3) | 1 |
| CLJ 3000/3600/3800 | Paper-Feed-Kit PFK-3000 | | |
| | RM1-2727 | Roller Assy 500 Sheet Tray | 1 |
| | RM1-2755 | Combined Pickup Roller Assy MP Tray and 250 Sheet Tray | 1 |
| | RM1-2699 | Separation Pad MP Tray | 1 |
| | RM1-2709 | Separation Pad 250 Sheet Tray | 1 |
| | RM1-2735 | Separation Pad 500 Sheet Tray | 1 |
| LJ 4345 | Paper-Feed-Kit PFK-4345 | | |
| | RL1-0019 | Pickup Roller MP Tray (Tray 1) | 1 |
| | RL1-0007 | Separation Pad MP Tray (Tray 1) | 1 |
| | RM1-0036 | Pickup Roller Tray 2 + 1500 Sheetfeeder | 3 |
| | RM1-0037 | Paper Feed Roller Tray 2 + 1500 Sheetfeeder | 6 |
| | PF2282K039NI | ADF Paper Pickup Roller Assembly | 1 |
| | PF2282K035NI | ADF Paper Separation Pad Assembly | 1 |